

# Smartvest Wireless Button

Art.-Nr. FUBE35020A

Seite 1 von 2



The Smartvest Wireless Button lets you control various Smartvest Wireless Alarm System actuators, such as the Wireless Socket, the Wireless Door Bell or even self-configured scenarios, within the system. The Wireless Button can be mounted using the click-mount for walls supplied, so that the button can be easily removed for mobile use. Alternatively it can be mounted using adhesive mounting. Two different actions can be triggered by assigning the action a short or long press. If the battery is low, this is transmitted to the alarm panel.

## Technologies

- Smartvest extension for controlling Smartvest actuators, i.e. Wireless Socket, Wireless Door Bell or self-configured scenarios
- Comes with a click-mount for walls, from which the button can be easily removed for mobile use. Alternatively it can be mounted using adhesive mounting.
- Individual configuration is possible for two actions (short/long press)
- Visual feedback via orange LED when starting up and in use
- Low battery notification sent to the Smartvest alarm control panel

## Technical data - Smartvest Wireless Button

Battery - battery operation	Yes
Battery - max. battery life	1,5 y
Battery - quantity	1
Battery - type	CR2032 (3V)
Colour	White
Compatible with Secvest	No
Compatible with Smartvest	Yes
Dimensions	(B x L x H) 30 x 17 x 70 mm
Display	LED

# Smartvest Wireless Button

Art.-Nr. FUBE35020A

Seite 2 von 2

## Technical data - Smartvest Wireless Button

Gross weight	0,058 kg
Housing material	Plastic
Max. humidity	80 %
Max. operating temperature	40 °C
Min. humidity	10
Min. operating temperature	-10 °C
Net weight	0,028 kg
Power consumption	0,014 mA
Radio frequency	868 MHz
Radio modulation	FSK
Standby power consumption	0,0086 mA
Tamper protection	No
Transmission power	4,5 dBm
Wireless range	(Depending on installation) 30 - 100 m