Smartvest Pro wireless keypad



Art.-Nr. FUBE45010 Seite 1 von 2



Embedded for on-site users

The alternative to the remote control and app: This wireless control panel with keypad and chip key reader installs permanently on the wall and is always there on the spot to control your Smartvest Pro wireless alarm system.

Phone battery dead? Misplaced your remote control? No problem with this Smartvest Pro wireless control panel: It's always right there on the spot, ready for you to control your alarm system by entering a code or using the Smartvest Pro ID key fob. You can set the rights for different users in no time using the Smartvest Pro app, including setting schedules for workers, for example.

The chic control panel can be installed in a flash, such as in the hall next to the front door. And of course it also ensures that you have plenty of time to leave your house when arming the alarm system or to come back in when disarming it.

Another practical function of the control panel when at least one member of the household is home: in the Smartvest Pro mode "internally armed", all integrated motion detectors are paused. Day, evening or night, so that all members of the household can move freely inside while magnetic contacts on doors and windows, for example, keep the home safe from break-ins. The Smartvest Pro wireless control panel is always there for you to work the main functions of the security system (arm, internally arm, disarm or directly trigger an alarm). For a comfortably secure home. For you and your family.

Technologies

- Optional Smartvest Pro wireless keypad control panel for arming and disarming the Smartvest Pro wireless alarm system (by entering a code or using a chip key)
- Backlit keys for optimal readability
- Clear feedback with every interaction (visual and, if required, acoustic)





Art.-Nr. FUBE45010 Seite 2 von 2

- Customised access controls based on a schedule (e.g. for workers, guests, cleaners)
- Dedicated button for triggering the panic alarm (with protection against unintentional triggering)
- Protected against tearing off/tampering (triggers alarm)
- Easy installation (screws and wall plugs included), e.g. in the hall next to the front door
- Includes easily replaceable battery, can also be operated via a standard power supply unit with USB-C connector (5 volts, 2 amperes)

Technical data - Smartvest Pro wireless keypad

Technical data Sindievest 116 Wheless keypad	
Alarming	Yes
Area of application	Interior
Battery - GRS type	AA
Battery - max. battery life	1 y
Battery - quantity	4
Battery - type	AA (1,5V)
Colour	white
DC voltage supply	5 V
Dimensions	147,5 x 89 x 30 mm
Display	LED
Gross weight	0,379 kg
Housing material	Plastic
Max. humidity	90 %
Max. operating temperature	40 °C
Min. humidity	10 %
Min. operating temperature	0 °C
Net weight	0,263 kg
Pet-proof	
Plug type	Type-C USB
Proximity keyfob	8 Smartvest Pro ID key fob (FUPC45000)
Radio frequency	868,3 MHz
Radio modulation	FSK
Reader type	Chip key reader and code entry
Sound pressure	75 dB
Standby power consumption	0,1 mA
Tamper protection	Yes
Transmission power	11.3 dBm
Wireless range	Depending on installation max. 100 m