Smartvest Pro ID key fob



Art.-Nr. FUPC45000 Seite 1 von 1



Disarming chip for kids and for you

Do your kids constantly forget your PIN code? Do you want to forget about entering a code or don't always have the remote control or app handy? Then use this practical chip key to disarm your Smartvest Pro.

You've just come home, you're still holding your house key and now you have to disarm your Smartvest Pro wireless alarm system as quickly as possible? Just hold this chip key up to the Smartvest Pro wireless keypad for a moment and press Disarm. It takes no time at all to attach the Smartvest Pro ID key fob to your set of keys so that it's always at your side. For a comfortably secure home. For you and your family.

Technologies

- Optional Smartvest Pro ID key fob control element for disarming the Smartvest Pro wireless alarm system at the Smartvest Pro wireless keypad (without entering a code)
- Sturdy design for long-lasting use in a set of keys, with robust metal bezel (repels dust, dirt and moisture)
- No battery necessary (RFID technology)

Technical data - Smartvest Pro ID key fob

Dimensions	40 x 35 x 10 mm
Gross weight	0,032 kg
Max. humidity	80 %
Max. operating temperature	40 °C
Net weight	0,012 kg